
## Installation Guide - Manual Pumped Heads

Quick guide

Fit your SeaSmart within 40 cms (16 inches) of your flush pump's inlet sanitation hose connection (or anywhere your inlet sanitation hose is accessible between the flush pump and the seacock – see page 3 'Installing






Close the inlet seacock. disconnect the inlet sanitation hose from the pump and connect the SeaSmart 'T' piece in its place.



Press the priming button for at least 40 seconds then flush your toilet. You'll see greentinted water coming through the system.







Slide the very thin sanitiser tube down inside the inlet sanitation hose and reconnect the sanitation hose onto the SeaSmart 'T' piece.





## TIP

If your sanitation hose is stiff and a bit difficult to disconnect or re-connect, try warming it up with some hot water.

To activate your warranty, email info@wessexchemicalfactors.co.uk or scan the QR code.

